




The Best There Is.

OWNER'S MANUAL

VERY IMPORTANT:

Save This Booklet. Carefully read this entire manual before using your new Browning firearm.

GOLD SEMI-AUTO 12 & 20 GA.

NEW GUN OWNERS RECORD

KEEP THIS RECORD FOR FUTURE REFERENCE

Browning Model

Serial Number

Gauge / Caliber

Purchase Price

Purchased From

Date of Purchase

Thank you for choosing a Browning Gold shotgun.

The Gold shotgun represents a new generation of Browning gas-operated semi-autos. The Gold 12 and 20 gauge incorporate the best of traditional Browning craftsmanship and advanced technology. Every detail of the Gold shotgun has been engineered to provide you the best in handling and reliable operation. With a reasonable amount of care your Gold semi-auto shotgun should give you many years of dependable, enjoyable service. Please feel free to write us immediately if you have any observations regarding its performance and operation.

Thank You.



*One Browning Place, Morgan, Utah 84050-9326
Distributed in Canada by Browning Canada Sports Ltd./Ltée
5617 Chemin St-Francois, St-Laurent, Quebec H4S 1W6*

Printed in Portugal

GOLD SEMI-AUTO 12 & 20 GA.

You Are Responsible For Firearms Safety

As a gun owner, you accept a set of demanding responsibilities. How seriously you take these responsibilities can be the difference between life and death. Failure to follow any of these instructions can cause extensive damage to your gun and/or possible serious injury or death to yourself and others.

THERE IS NO EXCUSE FOR CARELESS OR ABUSIVE HANDLING OF ANY FIREARM. AT ALL TIMES HANDLE ANY FIREARM WITH INTENSE RESPECT FOR ITS POWER AND POTENTIAL DANGER.

READ AND UNDERSTAND ALL OF THE CAUTIONS AND PROPER HANDLING PROCEDURES OUTLINED

IN THIS BOOKLET BEFORE USING YOUR NEW FIREARM.

1 ALWAYS KEEP THE MUZZLE OF ANY FIREARM POINTED IN A SAFE DIRECTION.

Do this even though you are certain it is unloaded. Never point any firearm at anything you do not intend to shoot. Be extremely alert and aware of all persons and property within the range of your ammunition.

2 NEVER RELY TOTALLY ON YOUR SHOTGUN'S MECHANICAL "SAFETY" DEVICE.

Always assume that your gun can be fired at any time, even with all safety mechanisms engaged. The word "safety" describes a gun's mechanical devices that are designed to place your gun in a **SAFER** status. No guarantee can be made that the gun will not fire even if the "safety" is in the "on safe" position. See "Operation of the Safety" later in this manual for instructions on operation of this gun's "safety."

LIKE ANY MECHANICAL DEVICE, A "SAFETY" CAN SOMETIMES FAIL; IT CAN BE JARRED OR

INADVERTENTLY MANIPULATED INTO AN UNSAFE CONDITION.

Mechanical "safeties" merely aid safe gun handling and are no excuse for pointing your shotgun's muzzle in an unsafe direction. While it is a good idea to "test" your gun's mechanical "safeties" periodically for proper function, **NEVER TEST THEM WHILE YOUR FIREARM IS LOADED OR POINTED IN AN UNSAFE DIRECTION.**

Safe gun handling does not stop with your gun's mechanical "safety" devices — it starts there. Always treat this shotgun with the respect due a loaded, ready-to-fire firearm.

NEVER TEST THE MECHANISM OF ANY FIREARM WHILE IT IS LOADED OR POINTED IN AN UNSAFE DIRECTION.

3 WHENEVER YOU HANDLE A FIREARM, OR HAND IT TO SOMEONE, MAKE SURE IT IS COMPLETELY UNLOADED.

Always open the action immediately, and visu-

ally check the chamber. Make certain that they do not inadvertently contain any ammunition. Always keep the chamber empty and "safety" in the "on safe" position unless shooting is imminent.

4 DO NOT TRANSPORT ANY LOADED FIREARM.

Keep all firearms unloaded during transport, whether stored in a holster, gun case, scabbard or other container.

5 HUNTING FROM ELEVATED SURFACES SUCH AS TREE STANDS IS DANGEROUS.

Doing so may increase the risk of handling a firearm. The following rules should always be observed by you and those you hunt with: **Always** make certain that the stand being used is safe and stable. **Always** make certain that your firearm is unloaded when it is being taken up and down from the stand. **Always** make certain that your firearm is not dropped from the stand, or dropped while it is being taken up or down from the stand. **Remember**, a loaded firearm may discharge when dropped, even with the safety in the "on safe" position.

6 **BEWARE OF BARREL OBSTRUCTIONS.**

Do this for the safety of both your gun and yourself. Mud, snow, and an infinite variety of other objects may inadvertently lodge in a barrel bore. It takes only one small obstruction to cause dangerously increased pressures that can ruin (swell or rupture) the finest shotgun barrels.

BEFORE CHECKING FOR A BARREL OBSTRUCTION, BE CERTAIN YOUR FIREARM IS FULLY UNLOADED.

Make sure no live rounds are in the chamber(s). Place the safety in the "on safe" position.

After assuring yourself that the firearm is completely unloaded, again, open the breech or action, and look through the barrel(s) to be sure it is clear of any obstruction. If an obstruction is seen, no matter how small it may be, clean the bore with a cleaning rod and patch as described later in this manual. Before the first firing, clean the bore with a cleaning rod

and patch, and wipe away any anti-rust compounds in the action/chamber areas.

7 **ALWAYS COMPLETELY UNLOAD ALL FIREARMS WHEN NOT IN USE.**

As a safety precaution, it is preferable to disassemble your gun for storage. Your responsibilities do not end when your firearm is unattended. Store your firearm and ammunition separately and well beyond the reach of children. Take all safeguards to ensure your shotgun does not become available to untrained, inexperienced or unwelcome hands.

8 **USE THE PROPER AMMUNITION.**

The barrel and action of all Browning firearms have been made with substantial safety margins over the pressures developed by established American commercial loads. Nevertheless, Browning assumes no liability for incidents which occur through the use of cartridges of nonstandard dimensions which develop pressures in excess of commercially available ammunition which has been loaded in accordance with standards established by

the Sporting Arms and Ammunition Manufacturers' Institute (SAAMI).

BE ALERT TO THE SIGNS OF AMMUNITION MALFUNCTION. IF YOU DETECT AN OFF SOUND OR LIGHT RECOIL WHEN A CARTRIDGE IS FIRED, DO NOT LOAD ANOTHER CARTRIDGE INTO THE CHAMBER.

Open the action and remove all cartridges from the chamber(s) as well as the action areas and magazine (when applicable). With the action open, glance down the barrel(s) to make sure that a wad or other obstruction does not remain in the barrel. Completely clear the barrel before loading and firing again. Failure to follow these instructions can cause extensive damage to your gun and possible serious injury to yourself and others.

MAKE SURE OF ADEQUATE VENTILATION IN THE AREA THAT YOU DISCHARGE A FIREARM. WASH HANDS THOROUGHLY AFTER EXPOSURE TO AMMUNITION OR CLEANING A FIREARM.

Lead exposure can be obtained from discharging firearms in poorly ventilated areas, cleaning firearms or handling ammunition. Lead is a substance that has been known to cause birth defects, reproductive harm and other serious injury.

9 **NEVER INSERT A SHELL OF THE INCORRECT GAUGE IN ANY SHOTGUN.**

The gauge of your shotgun is marked on the side of the barrel. Store all cartridges of different gauges in completely separate and well-marked containers. Never store shells of mixed gauges in a common container or in your pockets.

EXAMINE EVERY SHELL YOU PUT IN YOUR GUN. NEVER PUT A 20 GAUGE SHELL IN A 12 GAUGE GUN.

The most certain way to bulge or rupture a barrel is to drop a 20 gauge shell into a 12 gauge chamber. The 20 gauge shell, unfortunately, will not fall completely through the barrel; its rim is caught by the front of a 12 gauge chamber. Your gun will misfire (with the

chamber appearing to be empty). It is then possible to load a 12 gauge shell behind the 20 gauge shell. If the gun is fired, the result will be a so-called "12-20 burst" which can cause extensive damage to your gun and possible serious injury to yourself or others..

10 USE SHELLS OF THE CORRECT LENGTH.

Do not use 3 1/2" shotgun shells in a shotgun or barrel with a 2 3/4" chamber or 3" chamber. Do not use 3" shells in a shotgun chambered for 2 3/4" shells. Doing so can result in a build-up of dangerously high pressures that may damage your gun and possibly cause serious injury to yourself or others.

The size of the chamber is inscribed, along with gauge and choke designations, on the side of the barrel. The Gold semi-auto is chambered for 3" 12 or 3" 20 gauge loads.

11 DO NOT SNAP THE FIRING PIN ON AN EMPTY CHAMBER — THE CHAMBER MAY NOT BE EMPTY!

Treat every gun with the respect due a loaded gun, even though you are certain the gun is unloaded.

12 KEEP YOUR FINGERS AWAY FROM THE TRIGGER WHILE UNLOADING OR LOADING, UNTIL YOU ARE READY TO SHOOT.

13 BE SURE OF YOUR TARGET AND BACKSTOP.

Particularly during low light periods. Know the range of your ammunition. Never shoot at water or hard objects.

14 ALWAYS UNLOAD THE CHAMBER AND MAGAZINE OF ANY FIREARM BEFORE CROSSING A FENCE, CLIMBING A TREE, JUMPING A DITCH OR NEGOTIATING OTHER OBSTACLES.

Never lean or place any loaded firearm on or against a fence, tree, car, or other similar object.

15 WEAR EYE AND EAR PROTECTION WHEN SHOOTING.

Unprotected, repeated exposure to gunfire can cause hearing damage. Wear ear protectors

(shooting ear plugs or muffs) to guard against such damage. Wear shooting glasses to protect your eyes from flying particles. Allow proper distance (eye relief) between the scope and your eye when firing a scoped rifle or shotgun. Always keep a safe distance between the muzzle of your firearm and any persons nearby, as muzzle blast, debris and ejecting shells could inflict serious injury. Also, wear eye protection when disassembling and cleaning all firearms to prevent the possibility of springs, spring-tensioned parts, solvents or other agents from contacting your eyes.

16 DROPPING A LOADED GUN CAN CAUSE AN ACCIDENTAL DISCHARGE.

This can occur even with the "safety" in the "on safe" position. Be extremely careful while hunting or during any shooting activity, to avoid dropping any firearm.

17 IF ANY FIREARM FAILS TO FIRE, KEEP THE MUZZLE POINTED IN A SAFE DIRECTION.

Hold this position for a minimum of 30 seconds. Carefully open the action and remove the cartridge. If the primer is indented, the cartridge should be disposed of in a way that cannot cause harm. If the primer is not indented, your firearm should be examined by a qualified gunsmith and the cause of the malfunction should be corrected before further use.

18 BE DEFENSIVE AND ON GUARD AGAINST UNSAFE GUN HANDLING AROUND YOU AND OTHERS.

Don't be timid when it comes to gun safety. If you observe other shooters violating any of these safety precautions, politely suggest safer handling practices.

19 BE CERTAIN YOUR SHOTGUN IS UNLOADED BEFORE CLEANING.

Because so many gun accidents occur when a firearm is being cleaned, special and extreme care should be taken to be sure your gun is unloaded before disassembly, cleaning and re-assembly. Keep ammunition away from the cleaning location. Never test the mechanical function of any firearm with live ammunition.

20 SUPERVISE AND TEACH FIREARMS SAFETY TO ALL MEMBERS OF YOUR FAMILY — ESPECIALLY TO CHILDREN AND NONSHOOTERS.

Closely supervise newcomers to the shooting sports. Encourage enrollment in hunting/shooting safety courses.

21 NEVER DRINK ALCOHOLIC BEVERAGES OR TAKE ANY TYPE OF DRUGS BEFORE OR DURING SHOOTING.

Your vision and judgment could be dangerously impaired, making your gun handling unsafe to you and to others.

22 PERFORM PERIODIC MAINTENANCE. AVOID UNAUTHORIZED SERVICING.

Your new firearm is a mechanical device which will not last forever, and as such, is subject to wear and requires periodic inspection, adjustment, and service. Browning firearms should be serviced by a Browning Recommended Service Center or by Browning's service facility in

Arnold, Missouri. Browning cannot assume any responsibility for injuries suffered or caused by unauthorized servicing, alterations or modifications of Browning firearms.

23 READ AND HEED ALL WARNINGS in this instruction book, on ammunition boxes and with

all accessories that you install on your firearm. It is your responsibility to secure the most up-to-date information on the safe handling procedures for your Browning gun. Browning assumes no liability for incidents which occur when unsafe or improper gun accessories or ammunition combinations are used.

24 BROWNING RESERVES THE RIGHT TO REFUSE SERVICE ON FIREARMS THAT HAVE BEEN ALTERED, ADDED TO OR SUBSTANTIALLY CHANGED.


Removal of metal from barrel(s), or modifications of the firing mechanism and/or operating parts may lead to Browning's refusal of service on such firearms. Browning will charge the owner for parts and labor to return the firearm to original Browning specifications.

DO NOT, UNDER ANY CIRCUMSTANCES, ALTER THE TRIGGER, SAFETY OR PARTS OF THE FIRING MECHANISM OF THIS OR ANY OTHER FIREARM.

FAILURE TO OBEY THIS WARNING MAY RESULT IN INJURY OR DEATH TO YOURSELF OR OTHERS.

BE CAREFUL!


Figure 1-A



Nomenclature

In conventional gun terminology, the position and movement of shotgun parts are described as they occur with the shotgun horizontal and in normal firing position; i.e. the muzzle is forward or front; the butt stock is rearward or rear; the trigger is

downward or underneath; the sight is upward or on top. For general parts nomenclature (refer to Figure 1-A). The Browning Gold shotgun is shown disassembled to the extent necessary in order to follow instructions contained in this book (See Figure 1-B on the next page).

Figure 1-B

General Operation

The Browning Gold shotgun is a gas operated, semi-automatic shotgun. It is capable of shooting five shots (with the magazine plug removed using 2 3/4" loads) in rapid succession with each pull of the trigger. Upon firing, high pressure gas from behind the shot charge passes through two ports in the barrel, through the gas bracket and into the gas cylinder. High pressure gases force the gas piston rearward, applying pressure to the piston rod. As the piston rod moves rearward, it pushes the bolt assembly rearward, operating the action. As the bolt assembly moves rearward, it recocks the hammer, and ejects the fired shell. After full rearward travel, the bolt assembly returns forward, picking up a new shell from the magazine and chambers it automatically. After the last shell has been fired, the bolt assembly locks to the rear, instead of returning forward. This facilitates speedy reloading. The short-stroke of the gas piston along with the snug, gas sealing fit of the piston rod limits the amount of combustion gases blown out of the gas cylinder and into the receiver, keeping the inside of the receiver clean.


NOTE: The Gold shotgun is delivered with the magazine adapter in the magazine which limits the gun to three shots, in accordance with federal migratory bird laws. If you do not want your gun to be limited, merely take out the three shot adapter as explained on page 13 under "Three Shot Adapter."

Initial Cleaning

Various exposed metal parts of your new gun have been coated at the factory with a rust preventative compound. Before assembling your shotgun, clean the anti-rust compound from the inside of the barrel, receiver and the action-chamber areas. Browning Oil is ideal for removing this compound and for giving your new gun its first lubrication, however, any quality gun oil may be used. Clean the barrel using a cleaning rod and patch as explained under "Cleaning and Maintenance Suggestions" on page 17 and 18.

Serial Number

The serial number of your Gold shotgun is found on the left side of the receiver—just below the engraving "Gold Hunter."

Figure 2-A

Ammunition

The Gold 12 and 20 gauge shotguns shoot all factory lead and steel 12 or 20 gauge 2 3/4" and 3" loads.


Browning can assume no responsibility for incidents which occur through the use of cartridges of nonstandard dimension or those developing pressures in excess of SAAMI (Sporting Arms and Ammunition Manufacturer's Institute) established standards.

Operation of the Safety

The cross bolt safety prevents the trigger from being pulled when in the "on safe" position. The safety is located at the rear of the trigger guard (See Figure 2-A). In the "off safe" position a red warning band is visible on the safety button on the left side of the trigger guard. To place the gun "ON SAFE," press the safety button to the right. To move the safety to the FIRE position, press the safety to the left (See Figure 2-B).

The safety is reversible and can be reversed from right- to left-handed by a competent gunsmith. When installed, the left-handed safety will have the safety button's red warning band on the RIGHT side of the trigger guard.

NOTE: Do not depend on the red color alone to indicate your gun's safety status, as time, exposure to the elements, and the abrasive action of cleaning agents can erase it.

Figure 2-B

How to Assemble The Barrel to the Receiver

The Gold shotgun is delivered, in the box, with the barrel removed and the forearm still attached to the magazine tube. It is important to *follow the exact sequence* for assembly in steps 1 and 2, in order to properly assemble your Gold shotgun.



ALWAYS PLACE THE SAFETY IN THE "ON SAFE" POSITION BEFORE ASSEMBLY PROCEDURES AND CHECK YOUR GUN CAREFULLY TO BE CERTAIN

THAT THE CHAMBER, FEED MECHANISM AND MAGAZINE CONTAIN NO SHELLS.

- 1 Take the receiver in hand. First, lock the bolt rearward by pulling the operating handle fully to the rear. Remove the forearm from the magazine tube by unscrewing the magazine cap and sliding the forearm forward, off the magazine tube.


DO NOT SQUEEZE HARD ON THE OPEN REAR END OF THE FOREARM. TOO MUCH PRESSURE COULD CAUSE THE WOOD TO SPLIT.

- 2 Components of the gas system—the sleeve, sleeve spring and gas piston will remain in place and do not need to be removed, except for cleaning. If the components of the gas system have been removed, reinstall them as explained below. Otherwise, proceed to step 5.
- 3 Slide the sleeve onto the magazine tube with the piston rod end first. Check the piston rod to make sure it is aligned with the slot on the

Figure 3**Figure 4**

right side (ejection port side) of the receiver. Make sure the sleeve spring is properly positioned in the sleeve. (See Figure 3).

- 4 Slide the gas piston into the gas bracket. (See Figure 4).
- 5 With the gun in the vertical position, line the gas bracket and gas piston over the magazine tube (See figure 5). Slide the gas bracket and gas piston over the magazine tube. The barrel extension should slip solidly down into the receiver. Make sure the piston rod moves freely in its slot in the receiver.
- 6 Replace the forearm by sliding it onto the magazine tube and over the gas bracket so it seats securely. Install the magazine cap. Make sure the magazine cap is fully tightened down. Open and close the action several times and retighten the magazine cap. This will ensure a proper seal.

Figure 5



Disassembly of the Barrel From the Receiver

BEFORE STARTING DISASSEMBLY PROCEDURES, VISUALLY INSPECT THE CHAMBER, FEED MECHANISM AND MAGAZINE TO BE ABSOLUTELY CERTAIN THE SHOTGUN IS COMPLETELY UNLOADED. POINT THE BARREL IN A SAFE DIRECTION.

- 1 Unscrew the magazine cap and remove it.
 - 2 Remove the forearm by sliding it forward off the magazine tube.
 - 3 For cleaning, remove the barrel, piston and piston sleeve by sliding them forward off the magazine tube. See "Cleaning and Maintenance Suggestions" on page 17 and 18 for cleaning procedures.
- If you are disassembling for storage, return the piston and piston sleeve onto the magazine tube as shown previously in Figure 5. Reinstall the forearm over the magazine tube and screw on the magazine cap. You will then have two compact units: the barrel, and the action with forearm and stock.

CAUTION: AFTER THE BARREL HAS BEEN REMOVED FROM YOUR GUN, LEAVE THE BOLT IN THE OPEN POSITION. DO NOT PRESS THE CARRIER RELEASE BUTTON.

If the bolt is released forward with the barrel removed, the cartridge stop will hit the front of the receiver and cause damage.

Figure 6**Figure 7****Figure 8**

- 2 While holding the bolt handle, release the bolt to its forward position by depressing the carrier release button. Again use caution when releasing the bolt assembly to its forward position. If you allow the bolt assembly to slam closed with the barrel removed you can damage the receiver.
- 3 With the gun inverted, (trigger guard up) use a drive punch or similar object to push inward on the trigger guard pins, using caution not to

Disassembly of the Trigger Group and Bolt Assembly

The trigger group or bolt can be removed if the action becomes excessively dirty or wet. If this occurs, disassemble the action for a complete cleaning as explained below. Your Gold shotgun is designed to allow full disassembly of the trigger group and bolt assembly in the field, without any tools. Detailed cleaning procedures are outlined under "Cleaning and Maintenance" on page 17 and 18. Full disassembly involves removal of the bolt assembly and the trigger group. Any disassembly beyond this should only be performed by a competent gunsmith.

ALWAYS WEAR EYE PROTECTION WHEN PERFORMING ANY MAINTENANCE OR DISASSEMBLY.

REMOVING THE TRIGGER GROUP—

- 1 First, make certain the gun is totally unloaded and the "safety" is "on safe." **CHECK THE MAGAZINE, FEED MECHANISM AND CHAMBER TO BE SURE THEY DO NOT CONTAIN ANY SHELLS.**

scratch the receiver (See Figure 6). Trigger guard pins may be removed from either side of the receiver. Push the trigger guard pins clear through the other side of the receiver. It may be necessary to pull on the trigger pins to remove them from the receiver (See Figure 7).

- 4 Grasp the trigger guard and pull it up and out of the receiver. (See Figure 8)
- 5 Perform any cleaning of the parts and receiver cavity as necessary.

DO NOT DISASSEMBLE THE TRIGGER GROUP BEYOND THIS POINT.


REASSEMBLY—

- 1 Make sure the bolt is in the forward position.
- 2 Insert the trigger group back into the receiver. The holes in the trigger group should line up with the holes on each side of the receiver.
- 3 Reinsert the trigger guard pins and gently tap them into place with a plastic or wooden mallet, again using caution not to scratch the receiver.

IMPORTANT:

CAUTION: Browning

parts are made exclusively for Browning guns and are not recommended for use in other guns even though models may be similar. Inadequately fitted parts may be dangerous.



Parts List : Browning Gold semi-auto 12 & 20 ga. shotgun



When ordering parts please indicate the model name, serial number, stock style, and exterior finish.

Do not order parts using key numbers.

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
32	P160072	Action Spring 12 & 20 ga.	10	P160231	Magazine Cap Retainer 20 ga.
31	P160070	Action Spring Plunger 12 & 20 ga.	12	P014225	Magazine Cap 12 ga.
34	P160074	Action Spring Retainer 12 & 20 ga.	12	P160238	Magazine Cap 20 ga.
33	P160076	Action Spring Retainer Pin 12 & 20 ga.	12	P160234	Magazine Cap w/Eyelet 12 ga.
30	P160068	Action Spring Tube 12 & 20 ga.	12	P160235	Magazine Cap w/Eyelet 20 ga.
38-45	*P160160	Bolt Assembly 12 ga.	8	P160227	Magazine Follower 12 ga.
38-45	*P160162	Bolt Assembly 20 ga.	8	P160228	Magazine Follower 20 ga.
38	*P161160	Bolt 12 ga.	9	P160229	Magazine Spring 12 ga.
38	*P161162	Bolt 20 ga.	9	P160230	Magazine Spring 20 ga.
51	P160130	Bolt Cam 12 ga. & 20 ga.	11	P160232	Magazine Spring Retainer 12 ga.
52	P160132	Bolt Cam Retaining Pin 12 ga. & 20 ga.	11	P160233	Magazine Spring Retainer 20 ga.
46	P160120	Breechblock Assembly 12 ga.	13	P014280	Magazine Three Shot Adapter 12 ga.
46	P160122	Breechblock Assembly 20 ga.	13	P160240	Magazine Three Shot Adapter 20 ga.
28	P160030	Breechblock Buffer 12 ga.	7	P160040	Magazine Tube 12 ga.
28	P160032	Breechblock Buffer 20 ga.	7	P160044	Magazine Tube 20 ga.
87	P160355	Buttstock 12 ga. W/Pad	61	P160200	Mainspring 12 & 20 ga.
87	P160356	Buttstock 20 ga. W/Pad	60	P160198	Mainspring Plunger 12 & 20 ga.
81	*P160221	Carrier 12 ga.	62	P160201	Mainspring Plunger Pin 12 & 20 ga.
81	*P160223	Carrier 20 ga.	55	P160124	Operating Handle 12 & 20 ga.
76	*P160250	Carrier Dog Assembly 12 ga.	85	P160334	O-Ring 12 ga.
76	*P160255	Carrier Dog Assembly 20 ga.	85	P160338	O-Ring 20 ga.
80	P160285	Carrier Dog Lower Stop 12 & 20 ga.	86	P160332	O-Ring Retainer 12 ga.
79	P160283	Carrier Dog Spring 12 & 20 ga.	86	P160336	O-Ring Retainer 20 ga.
77	P160284	Carrier Dog Upper Stop 12 & 20 ga.	14	P160050	Piston Assembly 12 ga.
78	P160282	Carrier Dog Spring Guide 12 & 20 ga.	14	P160052	Piston Assembly 20 ga.
19	*P160090	Carrier Latch 12 ga.	15	P160053	Piston Outer Ring 12 ga.
19	*P160092	Carrier Latch 20 ga.	15	P160054	Piston Outer Ring 20 ga.
21	P160094	Carrier Latch Pin 12 & 20 ga.	16	P160057	Piston Valve Inner Ring 12 ga.
20	P160096	Carrier Latch Pin Clip 12 & 20 ga.	16	P160058	Piston Valve Inner Ring 20 ga.
22	P160098	Carrier Latch Spring 12 & 20 ga.	6	†P160010	Receiver w/ magazine tube 12 ga.
82	P160226	Carrier Spring 12 & 20 ga.	6	†P160020	Receiver w/ magazine tube 20 ga.
47	P160134	Cartridge Stop 12 & 20 ga.	89	P014318	Recoil Pad Screw
42/49	P160140	Cartridge Stop & Extractor Plunger 12 & 20 ga.	88	P160398	Recoil Pad Vent 12 ga.
48	P160136	Cartridge Stop Pin 12 & 20 ga.	88	P160399	Recoil Pad Solid 20 ga.
50	P160138	Cartridge Stop Spring 12 & 20 ga.	18	P160150	Return Spring 12 ga.
65	*P160205	Disconnecter 12 & 20 ga.	18	P160152	Return Spring 20 ga.
66	P160206	Disconnecter Pin 12 & 20 ga.	71	*P160210	Safety 12 & 20 ga.
67	P160207	Disconnecter Spring/Trigger Spring 12 & 20 ga.	72	P160211	Safety Plunger 12 & 20 ga.
40	P160164	Extractor 12 & 20 ga.	73	P160212	Safety Plunger Spring 12 & 20 ga.
39	P160166	Extractor Pin 12 & 20 ga.	68	*P160202	Sear 12 & 20 ga.
41	P160167	Extractor Spring 12 & 20 ga.	70	P160204	Sear Spring 12 & 20 ga.
4	P160588	Ejector 12 & 20 ga.	17	P160142	Sleeve Bar 12 ga.
45	P160168	Firing Pin 12 & 20 ga.	17	P160144	Sleeve Bar 20 ga.
43	P160171	Firing Pin Retaining Pin 12 ga.	35	P160078	Stock Bolt Plate 12 & 20 ga.
43	P160172	Firing Pin Retaining Pin 20 ga.	37	P160080	Stock Bolt Screw 12 & 20 ga.
44	P160170	Firing Pin Spring 12 & 20 ga.	36	P160082	Stock Bolt Washer 12 & 20 ga.
84	P160305	Forearm 12 ga.	63	*P160208	Trigger 12 & 20 ga.
84	P160315	Forearm 20 ga.	56	P161180	Trigger Guard 12 & 20 ga.
2	P160580	Front Sight, White 12 & 20 ga.	56-82	P160180	Trigger Guard Assembly 12 ga.
57	*P160192	Hammer 12 & 20 ga.	56-82	P160185	Trigger Guard Assembly 20 ga.
58	P160194	Hammer Link 12 & 20 ga.	29	P160034	Trigger Guard Buffer 12 & 20 ga.
59	P160197	Hammer Link Pin 12 & 20 ga.	83	P160213	Trigger Guard Pin 12 ga.
74	P160217	Hammer Pin & Trigger Guard Bushing 12 & 20 ga.	83	P160215	Trigger Guard Pin 20 ga.
53	P160125	Link 12 ga.	75	P160218	Trigger Guard Pin Retainer 12 & 20 ga.
53	P160126	Link 20 ga.	64-69	P160209	Trigger & Sear Pin 12 & 20 ga.
54	P160127	Link Pin 12 ga.			
54	P160128	Link Pin 20 ga.			
10	P014230	Magazine Cap Retainer 12 ga.			



* Indicates part must be fitted by Browning Service Department or qualified gunsmith.

† Part may be purchased only by holders of current valid Federal Firearms License.

Figure 9**Figure 10****Figure 11****REMOVING THE BOLT ASSEMBLY—**

To remove the bolt assembly it is preferred to first remove the trigger group, as explained previously.

- 1 With the gun inverted (trigger guard up position), push down on the cartridge stop while pulling outward on the bolt handle (See Figure 9). Remove the bolt handle from the bolt.
- 2 While keeping the cartridge stop depressed, slide the bolt and bolt slide forward and out of the receiver (See Figure 10).


Figure 12**Figure 13**

- 3 The bolt and bolt slide can be separated for cleaning (See Figure 11). Perform any cleaning of the bolt and receiver cavity as necessary.

DO NOT DISASSEMBLE THE BOLT ASSEMBLY BEYOND THIS POINT.

Reinstalling the Bolt Assembly

- 1 Reassemble the bolt and bolt slide.
- 2 Place the bolt assembly back in the receiver, bolt slide link end first (See Figure 12). Line the rails on the bolt slide with the slots in the bottom of the receiver.
- 3 Guide the bolt slide link into its socket in the recoil spring follower (See Figure 13).
- 4 To replace the operating handle push down on the cartridge stop and insert the bolt handle in its respective slot in the bolt. **IMPORTANT:** It may be necessary to pull out on the bolt handle slightly until the cartridge stop clicks

Figure 14**Figure 15**

back in place (See Figure 14). Failure to follow these instructions will result in the inability to load the magazine.

- 5 Open and close the action several times to make sure the bolt slide link and recoil spring follower are properly engaged.

Three Shot Adapter/Magazine Capacity

The Gold shotgun is delivered with the magazine three shot adapter (plug) installed in the magazine, limiting magazine capacity to two shells in compliance with federal migratory bird regulations. If you do not wish to be limited to three shots — when it is not required by law — you can remove (or reinstall) the three shot adapter (plug) as follows:

ALWAYS WEAR PROTECTIVE SAFETY GLASSES DURING THIS OPERATION.

- 1 First, make certain the gun is totally unloaded and the "safety" is "on safe." **CHECK THE MAGAZINE, FEED MECHANISM AND CHAMBER TO BE SURE THEY DO NOT CONTAIN ANY SHELLS.**

Figure 16

- 2 Unscrew the magazine cap and remove it.
- 3 The magazine three-shot adapter lays underneath the magazine spring retainer located in the forward end of the magazine tube. To remove the magazine spring retainer, depress the magazine spring retainer tab, located in the window on the magazine tube while keeping your hand on the magazine spring retainer. (See Figure 15). Slowly remove the magazine spring retainer as it is under pressure of the

magazine spring. Remove the magazine 3-shot adapter. (See Figure 16).

- 4 Depress the magazine spring back into the magazine tube and replace the magazine spring retainer. Make sure the magazine spring retainer tab is locked in place in its slot in the magazine slot.
- 5 Reinstall the magazine cap.


If, at some future time, you wish to limit your gun to three shots again, unscrew the magazine cap and remove the magazine spring retainer. Lightly press the three-shot adapter to force the magazine spring rearward until the base of the three-shot adapter is level with the end of the magazine tube. Replace the magazine spring retainer and magazine cap.

Loading Procedures

AT ALL TIMES DURING THE LOADING PROCEDURE, BE SURE YOUR MUZZLE IS POINTING IN A SAFE DIRECTION AND THE SAFETY IS IN THE "ON SAFE" POSITION.

There are two methods for getting a loaded shell into the chamber of your Gold shotgun.

Figure 17



Loading the chamber through the ejection port

- 1 After making sure the safety is "on safe," pull the operating handle to the rear until the bolt locks in the open position.

VISUALLY INSPECT THE CHAMBER, CARRIER AND MAGAZINE TO MAKE SURE THEY ARE CLEAR OF ANY OBSTRUCTIONS.

- 2 While pointing the muzzle in a safe direction, insert a cartridge of the proper gauge through

the ejection port into the open breech (See Figure 17). Press the carrier release button.

This will deliver the shell to the chamber. The chamber is now loaded.

- 3 With the chamber loaded, load the magazine to full capacity. To load the magazine, insert a shell, of proper gauge, through the loading port at the bottom of the receiver, up into the magazine, using your thumb to position it fully forward in the magazine tube (See Figure 18). Make sure the rim of the shell engages the cartridge stop and is held fully inside the magazine tube. It will make an audible click when fully inserted.

Loading the Chamber Manually from the Magazine — Speed Loading

- 1 ***MAKE SURE THE MUZZLE IS POINTED IN A SAFE DIRECTION AND THE SAFETY IS IN THE "ON SAFE" POSITION.***
- 2 With the bolt open, insert a shell into the magazine. The shell will be automatically cycled from the magazine to the chamber.

Figure 18



KEEP YOUR FINGERS CLEAR OF THE EJECTION PORT.

- 3 Load the magazine to full capacity as explained previously.

CAUTION: WHENEVER A SHELL HAS BEEN CYCLED INTO THE CHAMBER — AUTOMATICALLY OR MANUALLY — THE SHOTGUN IS READY TO FIRE BY SIMPLY MOVING THE SAFETY TO THE OFF SAFE POSITION.

Unloading

CAUTION: WHENEVER UNLOADING, ALWAYS BE CERTAIN THAT THE MUZZLE IS POINTED IN A SAFE DIRECTION AND THAT THE SAFETY IS IN THE "ON SAFE" POSITION.

- 1 Unload your Gold shotgun by grasping the operating handle and cycling the action until all rounds are ejected.

ALWAYS INSPECT THE CHAMBER, ACTION, CARRIER AND MAGAZINE VERY CAREFULLY AFTER UNLOADING TO BE SURE ALL LIVE ROUNDS ARE CLEARED FROM THE GUN.

Breech Remains Open After the Last Shot

The breech of the Gold shotgun remains open, with the bolt locked to the rear, after the last shot has been fired. This allows convenient and fast re-loading.

- 1 Place the safety in the "on safe" position.
- 2 Drop an appropriate shell into the open breech or into the magazine.

- 3 Close the action by depressing the carrier release button.
- 4 Load the magazine.

EVEN WITH THE BREECH LOCKED OPEN AFTER SHOOTING, DO NOT ASSUME YOUR SHOTGUN IS UNLOADED. ALWAYS INSPECT THE CHAMBER, CARRIER AND MAGAZINE TUBE TO BE SURE THEY CONTAIN NO CARTRIDGES.

Firing Your Gold shotgun

With the chamber loaded, all that is necessary to fire the gun is to push in on the safety so that the red warning band is visible on the left side of the trigger guard and pull the trigger.

The gas system ejects the fired shell and picks up a new shell from the magazine and chambers it automatically. This is repeated each time you pull the trigger until the last shell has been fired.

AFTER SHOOTING, IMMEDIATELY PLACE THE "SAFETY" IN THE "ON SAFE" POSITION.

Invector Interchangeable Choke System

20 GAUGE STANDARD INVECTOR—

The 20 gauge Gold shotgun's barrel is threaded to accept the Browning Standard Invector Interchangeable Choke System. The word INVECTOR denotes that the barrel is threaded. The degree of choke is indicated twice on each choke tube: Inscribed on the side of the tube, and indicated with a "notch" code on the top rim of the tube. Browning 20 gauge Standard Invector choke tubes are made with tempered steel and are fully compatible with all **FACTORY AMMUNITION** (loaded in compliance with SAAMI specifications) including Magnum lead and steel shot loads and rifled slug loads. Browning's universal tube wrench is used to remove and install these tubes.

12 GAUGE INVECTOR-PLUS —

The 12 gauge Gold shotgun has a back-bored barrel and is threaded to accept Invector-Plus choke tubes only. They are *not* interchangeable with 12 gauge Standard Invector choke tubes. Do not use Invector-Plus tubes in barrels threaded for Standard Invector tubes. Do not use Standard Invector

tubes in barrels threaded for Invector-Plus tubes. Failure to follow these warnings may damage your gun and cause injury to yourself and others. A special "Plus" choke tube wrench is provided to remove and tighten Invector-Plus choke tubes.

DO NOT FIRE THIS SHOTGUN WITHOUT HAVING AN INVECTOR CHOKE TUBE INSTALLED. Permanent damage may result to the threads.

DO NOT USE BROWNING INVECTOR CHOKE TUBES IN ANY SHOTGUN BARRELS NOT SUPPLIED BY BROWNING. ALSO, DO NOT USE ANY OTHER CHOKING DEVICE IN ANY SHOTGUN BARRELS SUPPLIED BY BROWNING. USE ONLY CHOKE TUBES MARKED INVECTOR.


CAUTION: WHENEVER HANDLING ANY SHOTGUN FOR THE PURPOSE OF REMOVING OR INSTALLING A CHOKING DEVICE, MAKE ABSOLUTELY CERTAIN THE GUN IS FULLY UNLOADED, AND THE BOLT OR BREECH IS OPEN! NEVER ATTEMPT TO REMOVE OR INSTALL A SHOTGUN CHOKING DEVICE ON A LOADED FIREARM!

TUBE REMOVAL—

- 1 ***UNLOAD YOUR GOLD SHOTGUN FULLY. INSPECT THE CHAMBER, FEED MECHANISM AND MAGAZINE TO MAKE SURE THEY DO NOT CONTAIN ANY SHELLS.***
- 2 Open the action, locking it rearward, and place the "safety" in the "on safe" position.
- 3 Use the Invector wrench to loosen the tube, turning it counterclockwise. Finger twist the tube the rest of the way out of the barrel.

TUBE INSTALLATION—

- 1 ***UNLOAD YOUR GOLD SHOTGUN FULLY. INSPECT THE CHAMBER, FEED MECHANISM AND MAGAZINE TO MAKE SURE THEY DO NOT CONTAIN ANY SHELLS.***
- 2 Open the action and place the "safety" in the "on safe" position.
- 3 Before installing a tube, check the internal choke tube threads in the muzzle, as well as the threads on the Invector choke tube to be sure they are clean. Lightly oil the threads with an oil like Browning Oil.

Figure 19

- 4 Using your fingers, screw the appropriate tube into the muzzle end of the barrel, tapered end first, notched end outward. When it becomes finger-tight, use the Invector choke tube wrench to firmly seat the tube.

THE INVECTOR CHOKE TUBE SHOULD BE PERIODICALLY CHECKED TO ASSURE THAT IT IS TIGHT AND FIRMLY SEATED. BEFORE CHECKING, FOLLOW THE SAFETY GUIDELINES OUTLINED ABOVE.

Replacement and additional tubes and wrenches are available from your Browning dealer, or by writing:

Browning Consumer Department
One Browning Place
Morgan, Utah 84050-9326
(801) 876-2711.

Canadian customers please call or write:

Browning Canada Sports Ltd./Ltee
5617 Chemin St-Francois
St-Laurent, Quebec H4S 1W6.
(514) 333-7261.

INVECTOR CHOKE TUBE CODE—

To identify individual Invector tubes, refer to the abbreviated indications on the side of the tube, or use the identification mark(s) located on the top rim of each tube. (See Figure 19).

INVECTOR TUBE SELECTION—

To help you choose the correct choke tube for each hunting situation, all Browning Invector choke tubes are inscribed on the side with the patterns they produce with both lead and steel shot. Each Invector tube also has notches on the top rim of the tube. These notches are a code to allow you to determine the choke designation while the tube is installed. Rim notches refer specifically to lead shot. You will need to use the chart below to cross-reference from lead to steel, and determine the appropriate tubes for your ammunition and hunting/shooting situation.

20 GAUGE STANDARD INVECTOR

Rim Notches	Pattern With Lead Shot	Pattern With Steel Shot
I	Full	Full
III	Modified	Imp. Modified
III	Imp. Cylinder	Modified ¹
IIII	Skeet	Modified ¹
No Notches	Cylinder	Imp. Cylinder

¹When more than one choke designation is listed for a given steel shot pattern, use the more open choke listed for high velocity, larger shot size steel loads.

12 GAUGE INVECTOR-PLUS

Rim Notches	Pattern With Lead Shot	Pattern With Steel Shot
Knurled**	X-Full Turkey	**
I	Full	*
II	Imp. Modified	Full ¹
III	Modified	Full ¹
III	Imp. Cylinder	Modified
IIII	Skeet	Imp. Cylinder
No Notches	Cylinder	Cylinder

*Not for use with steel shot. Using an over-tight choke constriction with steel shot will result in an ineffective, "blown" pattern.

**Extra Full Special with knurled rim. Do not use with steel shot.

¹When more than one choke designation is listed for a given steel shot pattern, use the more open choke listed for high velocity, larger shot size steel loads.

Figure 20

GOLD SEMI-AUTO MAGAZINE CAPACITY

Shell Size	With 3-shot Adapter	Without 3-shot Adapter
*2 3/4"	2	4
*3"	2	3

*The Gold shotgun handles mixed loads of 2 3/4" and 3" shells.

Use of Extra Barrels

All Browning Gold semi-auto shotgun barrels are completely interchangeable within gauge. No special fitting is required.

Cleaning and Maintenance Suggestions

You should clean your Gold shotgun whenever it becomes excessively dirty. The barrel should be cleaned and the action wiped clean and oiled after every day of shooting. The gas system should require only occasional cleaning. If a malfunction occurs, perform a thorough cleaning, to see if it solves the problem, before seeking the services of a Browning Recommended Service Center, the Browning Service Facility in Arnold, Missouri, or a competent gunsmith.

Normal maintenance can be accomplished with the barrel still attached to the receiver (oiling and wiping down). More careful cleaning requires removal of only the barrel from the receiver (cleaning the barrel), and the removal of several gas sys-

tem components. A complete cleaning requires removal of the bolt and trigger group.

PERIODIC OILING —

Ordinary good judgment will indicate that the metal parts of a gun should receive a light film of oil after the gun has been exposed to weather or handling.

Occasionally a small drop of light gun oil may be placed inside the receiver on the rails on which the bolt slides (See Figure 20). This will help to relieve friction and ensure smooth operation.

If the gun has been exposed to a lot of dust, dirt, mud or water, the principal working parts including the gas system, should be wiped clean and lubricated with a light film of oil. Browning Oil is recommended.

DO NOT POUR LARGE QUANTITIES OF OIL INTO THE ACTION. A LARGE EXCESS OF OIL WILL RUN BACK INTO THE WOOD OF THE STOCK AND CAUSE SOFTENING OF THE WOOD, WITH CONSEQUENTIAL LOOSENING OF THE STOCK.

CLEANING THE BARREL —

- 1 **BE CERTAIN YOUR SHOTGUN'S MAGAZINE, FEED MECHANISM AND CHAMBER ARE UNLOADED. PLACE THE "SAFETY" IN THE "ON SAFE" POSITION AND LOCK THE BOLT TO THE REAR. ALWAYS WEAR PROTECTIVE SAFETY GLASSES DURING ALL DISASSEMBLY AND CLEANING PROCEDURES.**
- 2 Remove the barrel so that it can be cleaned from the breech end (See "Disassembly" on page 8).
- 3 Using a shotgun cleaning rod with tip and patch large enough for a snug fit in the bore, insert the rod and patch in the breech end of the barrel and run back and forth through the bore several times. Remove and wipe the Invector tube, threads and barrel threads with a brass or nylon brush, and lightly oil.
- 4 Inspect the bore from both ends for leading by looking through the bore toward light. Leading will appear as dull longitudinal streaks and is usually more predominant near the muzzle and just forward of the chamber.

- 5 A normal amount of leading can be expected with today's high-velocity loads and improved wads but this is not serious. If or when leading should become heavy, it can be removed with a brass bore brush. Make sure a choke tube is installed. Spray the bore or the bore brush with a good powder solvent, and scrub the bore until leading is removed. To prevent brass bristles from breaking off, the brush should be pushed completely through the bore before being withdrawn.
- 6 After leading has been removed, the bore should be wiped dry with a clean patch, and then a lightly oiled patch run through it for preservation.
- 7 Reassemble barrel and wipe all exposed metal surfaces with an oiled cloth making sure to wipe gun clean of all finger marks where moisture will accumulate.
- 8 The barrel and action should be inspected to assure that all cleaning patches have been re-

moved and not inadvertently left in the barrel or action.

- 9 The wood surfaces can also be wiped with Browning Oil or they can be polished with any quality furniture wax (but not both).

CLEANING THE ACTION AND TRIGGER GROUP —

- 1 When the action becomes excessively dirty, remove the trigger group and bolt assembly from the receiver as explained under "Full Disassembly" on page 9 and 12. Clean with an oil such as Browning Oil or a gun solvent as necessary, using an old toothbrush to loosen any caked-on grime. Wipe the receiver cavity clean. Lightly oil the cavity (aerosol Browning Oil is ideal) and wipe it dry. No further disassembly is required for cleaning.

- 2 Reassemble the trigger group, bolt assembly, gas system and the barrel to the receiver as explained previously. Then wipe all exposed metal surfaces with an oiled cloth, making sure to wipe clean all finger marks where moisture will accumulate.
- 3 The barrel and action should be inspected to assure that all cleaning patches have been removed and not inadvertently left in the barrel or action.

CLEANING THE GAS SYSTEM—

- 1 Remove the gas piston and piston sleeve from the magazine tube. Spray the magazine tube with a good quality powder solvent and wipe clean.
- 2 Spray the piston and piston sleeve with a good powder solvent and brush it thoroughly to remove any deposits (an old toothbrush is ideal). Spray the inside and wipe off any buildup. It will be easier to remove the piston sleeve

spring to clean the interior of the piston sleeve. **NEVER** use a steel brush on any of the gas components.

- 3 Complete the cleaning of the gas system by applying a very light film of Browning Oil to all parts for protection and lubrication.

DO NOT TAKE YOUR GUN'S ACTION APART BEYOND WHAT IS EXPLAINED IN THIS

MANUAL. This is a specialized, finely fitted mechanism; an attempt to remove the inner mechanism may mar it for life. It is unnecessary, and may do damage to the inner mechanism, to disassemble it for routine cleaning and oiling. Of course, misfortunes (such as dropping your gun in water) require appropriate attention, and in such circumstances we recommend you immediately take your gun to a competent gunsmith.

Service or Repair

If your firearm should require service or repairs, we suggest you first contact a local recommended Browning Firearms Service Center. Contact your Browning sporting goods dealer or call our Service Department for the address of the Service Center nearest you. Otherwise, you may send your firearm directly to our own Service Department. For technical questions about your firearm or service call our Service Department.

Browning Service Department
3005 Arnold Tenbrook Road
Arnold, Missouri 63010-9406
Phone: 1-800-322-4626

Canadian Customers call or write:

Browning Canada Sports Ltd./Ltee,
5617 Chemin St-Francois
St-Laurent, Quebec H4S 1W6
Phone: (514) 333-7261

When returning your firearm for servicing, you *must* do the following:

- a. Be sure it is completely unloaded.
- b. Package it securely in a cardboard container.
- c. Enclose a letter with your firearm that clearly describes the trouble experienced and the repairs or alterations desired.
- d. If convenient, send a copy of the letter to us separately.
- e. Never return ammunition with your firearm. It is against postal and most commerce regulations.

If you have any questions about this manual or about any other Browning products, call or write our Consumer Information Department:

Browning Consumer Information
Morgan, Utah 84050
Phone: (801) 876-2711