


**MASSACHUSETTS SUPPLEMENT
SIG SAUER P232 PISTOL**

To comply with the provisions of 940 CMR 16.00 (as promulgated by the Attorney General, Commonwealth of Massachusetts) your SIG Sauer Pistol is equipped with a load indicator, the purpose of which is to plainly indicate whether or not a cartridge is in the firing chamber of the handgun.

WARNING

**THE LOAD INDICATOR IS NOT A SUBSTITUTE FOR
SAFE FIREARMS HANDLING - FOLLOW ALL SAFETY
WARNINGS IN YOUR OWNERS MANUAL**




**SEE REVERSE SIDE FOR LOADED
AND UNLOADED CHAMBER INDICATIONS.**

SIGARMS®

PRECISION FIREARMS


LOADED CHAMBER INDICATION

The extractor will extend outward from the slide and the red dot will be exposed when a round is in the firing chamber.



WARNING - The loaded chamber indication is **NOT** a substitute for safe firearms handling. **ALWAYS** pull back the slide & visually check the chamber to confirm the chamber is empty. **NEVER** assume the firearms is unloaded.

UN-LOADED CHAMBER INDICATION



Note: With no round in the chamber, the extractor will remain flush with the slide.

SIGARMS[®]

PRECISION FIREARMS